


OUTHOUSE[™] BLIND

Patent Pending

Instruction Manual




Be sure to follow these guidelines for using your Outhouse[™]

READ ALL INSTRUCTIONS and WARNINGS FIRST

Any questions or confusion regarding the use of this product contact our Customer Service Department at Ameristep[®] (810) 686-4035 before using.

COMPONENTS

OUTHOUSE™ BLIND




- A. Window Openings
- B. Stake Loops (8 Stakes Included)
- C. Door Zipper
- D. High Wind Tie-Down Loops (4 High Wind Tie-Downs Included)



PARTS LIST:

- 1 Outhouse™ Blind (68" square x 78" Tall)
- 4 Windows
- High Wind Tie-Downs
- Wheelchair Accessible Entrance
- 1 Camouflage Back Pack



ACCESSORIES



Swivel Tripod Stool



Blaze Orange™ Blind Cap



Snow Tangle™ Blind Cover



Archers Chair



Director's Chair



Grizzly™ Folding Deer Cart

STORAGE & SAFETY TIPS

- **NEVER USE A HEATER IN YOUR BLIND - UNVENTED FUMES COULD CAUSE SICKNESS OR DEATH**
- Store your Blind in a cool dry place
- Store your Blind free of dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for extended periods of time as it will cause unnecessary fading of the material.
- To stop any leakage, use seam sealer on all seams and silicon spray on the sidewalls.

See our full line of accessories on our website.
Replacement Parts are also available

SET-UP

OUTHOUSE™ BLIND

WARNING: The Outhouse™ Blind is constructed of Spring Steel - Open with extreme caution, holding the blind away from face, body and other people.

The lightest fully enclosed Blind.

No other blind delivers the level of transportability and concealment that you'll find in the original Ameristep® Outhouse™ Blind



Step 1:

Remove the pouch containing the high wind tie-downs. Remove your Outhouse™ blind from the carrying pouch.



Step 2:

Hold one of the 2 ring sets of steel. Let the other two pop open.



Step 3:

Spread your Outhouse™ Blind and stake down. High wind tie-downs are included (if needed)



TAKE-DOWN OUTHOUSE™ BLIND

IMPORTANT:

BEFORE take-down of your Outhouse™ remove all high wind tie-downs and ground stakes. Make sure that it is **COMPLETELY DRY** and free from dirt and any debris.



STEP 1:

Remove all ground stakes and high wind tie-downs. Fold the blind in half laying flat on the ground.



STEP 2:

Take hold of the bottom corners at the bottom of your Outhouse™ Blind.

STEP 3:

Begin to fold the top towards the bottom of the blind forming a "taco" shape.



STEP 4:

Draw your arms together, roll the top of the blind over while overlapping the 2 steel bands.

STEP 5:

Draw your arms in together. Grab both hoops with your right hand allowing your left hand to be free. With your left hand grab the 12 o'clock position and pull it towards you. Continue to push down overlapping the rings; tucking each ring until they lay flat.



STEP 6:

Draw your arms together, roll the top of the blind over while overlapping the 2 steel bands.

Insert your folded Outhouse™ Blind into your back pack carry case.

Pack ground stakes, and high wind tie-downs in the pouches provided. Store them with your Ameristep® Blind for your next hunting adventure.

